

# RACK MAGIC SIPHON INSTRUCTIONS

## SET UP

---

**Note:** It is highly recommended that you use 5/16" tubing (not included) with your Rack Magic but 3/8" tubing will work as well.

1. Dip one end of the tubing into hot water to soften.
2. Push softened end of tubing over the cane portion of the Rack Magic for about 1/2".

## SANITIZE

---

**Note:** The seal of the Rack Magic must be wet in order to slide inside of the tubing. To avoid the racking cane sticking in the Rack Magic, ensure that the seal is wet before use.

1. Place the tip of siphon in sanitizer and pump cane a few times to force sanitizer through inside of siphon and tubing.
2. Rinse outside of siphon and tubing in sanitizer.
3. Sanitize vessel that you are going to transfer into.

## USE

---

1. Your Rack Magic uses gravity to transfer liquid. Therefore, make sure your full vessel is placed well above your sanitized vessel.
2. Place tip of siphon into full vessel and end of tubing into empty sanitized vessel.
3. Pump the cane of your siphon until you see liquid flow through the top of the cane. Your liquid will start to flow down the tubing and fill the empty vessel.
4. Now you can stop pumping and the liquid will continue to flow.

## TIPS

---

1. Keep the tip of your siphon above any sediment that has settled in the bottom of the vessel. It is better to give up a little beer or wine than to transfer the sediment.
2. The Rack Magic can be taken completely apart for cleaning. For reassembly see image below.

## REASSEMBLY

---

